

household products

家庭用品系列



Great for both
INDOORS and
OUTDOORS
適合家居及
戶外使用

323/258
Garbage tank with swing cover
搖蓋垃圾桶
427 x 337 x H.668mm
16-3/4" x 13-1/4" x H.26-1/4"
42 L / 9.23 gal
I 4 pcs / 6,107 (0.171)
II 4 pcs / 6,609 (0.185)
III 684 pcs / 632 pcs
IV 1,368 pcs / 1,264 pcs



320
Waste basket (Slim version)
窄身字紙桶

310 x 183 x H.362mm
12-1/4" x 7-1/4" x H.14-1/4"
15.75 L / 3.46 gal
I 12 pcs / 3,564 (0.100)
II 12 pcs / 3,917 (0.110)
III 3,528 pcs / 3,216 pcs
IV 7,056 pcs / 6,432 pcs



321
Swing lid (Slim version)
窄身字紙桶蓋

(Fit 適合 No.320)
320 x 185 x H.355mm
12-5/8" x 7-3/8" x H.1-3/8"
I 12 pcs / 1,147 (0.032)
II 48 pcs / 4,899 (0.137)
III 10,980 pcs / 10,272 pcs
IV 21,960 pcs / 20,544 pcs

- Manufactured with special "Fire Retardant" material. 特別選用阻燃塑料注塑。
- "Under normal use, these garbage cans & covers are non flammable, the material will retard burning item inside and does not release toxic fumes". 在正常情況下使用，當桶內燃燒之物品燒盡時，桶身及桶蓋均不會繼續燃燒，更不會產生對人體有害之氣體。



316R
Fire retardant waste basket
不助燃長方形字紙桶
285 x 243 x H.330mm
11-1/4" x 9-5/8" x H.13"
15 L / 3.30 gal
I 12 pcs / 2,138 (0.060)
II 24 pcs / 4,688 (0.131)
III 5,892 pcs / 5,129 pcs
IV 11,784 pcs / 10,258 pcs



260R/263R
Fire retardant garbage tank with swing cover
不助燃長方形搖蓋字紙桶
389 x 273 x H.519mm
15-1/4" x 10-3/4" x H.20-3/8"
31 L / 6.81 gal
I 6 pcs / 3,676 (0.103)
II 6 pcs / 4,088 (0.114)
III 1,710 pcs / 1,536 pcs
IV 3,420 pcs / 3,072 pcs



259R/260R
Fire retardant garbage tank with cover
不助燃長方形字紙桶蓋
384 x 264 x H.457mm
15-1/8" x 10-3/8" x H.18"
31 L / 6.81 gal
I 6 pcs / 3,268 (0.091)
II 6 pcs / 3,542 (0.099)
III 1,926 pcs / 1,776 pcs
IV 3,852 pcs / 3,552 pcs



318R
Fire retardant waste basket
不助燃長方形字紙桶
283 x 190 x H.280mm
11-1/8" x 7-1/2" x H.11"
10 L / 2.20 gal
I 12 pcs / 1,394 (0.039)
II 24 pcs / 3,094 (0.087)
III 9,036 pcs / 8,136 pcs
IV 18,072 pcs / 16,272 pcs



317R/318R
Fire retardant waste basket with swing cover
不助燃長方形搖蓋字紙桶
287 x 200 x H.341mm
11-1/4" x 7-7/8" x H.13-3/8"
10 L / 2.20 gal
I 6 pcs / 1,238 (0.035)
II 24 pcs / 5,467 (0.153)
III 5,088 pcs / 4,608 pcs
IV 10,176 pcs / 9,216 pcs

- With "Easy open and close" functions. 擲架開關操作容易。
- To use: Open the handle for garbage dumping. 使用：開啟擲架，擺放托盤於架上，將背心膠袋套在手柄上，便可使用。
- When not in use: Close the handle to keep environment clean and hygienic. 收藏：將擲架手柄合走，托盤掛在擲架上之掛勾，可節省地方及保持清潔。
- Made with polypropylene for easy daily cleaning. 選用聚丙烯製造，容易清潔。



Hang the tray on the hook for easy storage. 掛勾設計可將托盤懸掛，易於存放。



448
Shopping bag support rack
環保購物袋擲架
343 x 270 x H.350mm
13-1/2" x 10-5/8" x H.13-3/4"
I 6 pcs / 0,945 (0.026)
II 24 pcs / 4,175 (0.117)
III 6,666 pcs / 6,024 pcs
IV 13,332 pcs / 12,048 pcs

- Rack 擲架：355 x 266 x H.350mm (Open 開啟)
- Rack 擲架：268 x 500mm (Close 收藏)
- Tray 托盤：303 x 198 x H.20mm

dust pan with broom

- Dust pan size (up-right position)
垃圾簕直立尺碼：
278 x 115 x H.990mm
- Broom size (total length)
掃把全長尺碼：
H.940mm



387
Dust pan with broom
垃圾簕連掃把
278 x 115 x H.990mm
11" x 4-1/2" x H.39"
I 6 pcs / 4,708 (0.132)
II 12 pcs / 5,010 (0.140)
III 1,338 pcs / 2,508 pcs
IV 2,676 pcs / 5,016 pcs


- Will stand in up-right position
可作直立式擺放



- Has larger than average dust pan capacity
垃圾簕體積較大可容納更多垃圾。
- Specially designed edge for better dust collection
緊貼地面的設計，更易於掃起垃圾。



- Snap fit handle holds brush and dust pan together
子母式手柄，可以把垃圾簕及掃把扣起。



- Swirl head feature makes cleaning easy at any angle
有旋轉刷頭，可清潔任何角度



447
Plastic portable garbage bag holder
塑膠輕便組合垃圾桶
Extended size 伸展尺寸：
370 x 294 x H.670
14-1/2" x 11-1/2" x H.26-3/8"
Folded size 摺合尺寸：
370 x 294 x H.60
14-1/2" x 11-1/2" x H.2-3/8"
I 6 pcs / 1,510 (0.042)
II 12 pcs / 3,364 (0.094)
III 4,170 pcs / 3,744 pcs
IV 8,340 pcs / 7,488 pcs



381
Brush & dust pan
小型掃把及垃圾簕
211 x 182 x H.32mm
8-1/4" x 7-1/8" x H.1-1/4"
I 12 pcs / 0,625 (0.018)
II 48 pcs / 2,821 (0.079)
III 20,136 pcs / 17,856 pcs
IV 40,272 pcs / 35,712 pcs




377
Dust pan (Shovel shape)
垃圾簕
210 x 256 x H.63mm
8-1/4" x 10-1/8" x H.2-1/8"
handle 手柄：104mm / 4-1/8"
I 24 pcs / 0,973 (0.027)
II 96 pcs / 4,316 (0.121)
III 25,896 pcs / 23,328 pcs
IV 51,792 pcs / 46,656 pcs




385
Dust pan
垃圾簕
243 x 226 x H.143mm
9-5/8" x 8-7/8" x H.5-5/8"
I 24 pcs / 1,154 (0.032)
II 72 pcs / 3,770 (0.106)
III 21,816 pcs / 20,016 pcs
IV 43,632 pcs / 40,032 pcs



386
Dust pan
垃圾簕
280 x 253 x H.163mm
11" x 10" x H.6-3/8"
I 24 pcs / 1,672 (0.047)
II 48 pcs / 3,658 (0.102)
III 15,072 pcs / 13,776 pcs
IV 30,144 pcs / 27,552 pcs



384 (S/小)
Dust pan with handle
有柄垃圾簕
273 x 253 x H.120mm
10-3/4" x 10" x H.4-3/4"
handle 手柄：711mm / 28"
I 12 pcs / 1,385 (0.039)
II 36 pcs / 4,565 (0.128)
III 9,096 pcs / 8,280 pcs
IV 18,192 pcs / 16,560 pcs



388 (M/中)
Dust pan with handle
有柄垃圾簕
294 x 294 x H.136mm
11-5/8" x 11-5/8" x H.5-3/8"
handle 手柄：711mm / 28"
I 12 pcs / 1,594 (0.045)
II 36 pcs / 5,176 (0.145)
III 9,096 pcs / 8,280 pcs
IV 18,192 pcs / 14,544 pcs



389 (L/大)
Dust pan with handle
有柄垃圾簕
335 x 316 x H.170mm
13-1/4" x 12-1/2" x H.6-5/8"
handle 手柄：711mm / 28"
I 12 pcs / 2,140 (0.060)
II 24 pcs / 4,694 (0.131)
III 5,880 pcs / 5,352 pcs
IV 11,760 pcs / 10,704 pcs



449
Plastic reusable-bag storage
膠袋收集籃
165 x 132 x H.310mm
6-1/2" x 5-1/4" x H.12-1/4"
I 24 pcs / 1,567 (0.044)
II 48 pcs / 3,721 (0.104)
III 16,080 pcs / 13,536 pcs
IV 32,160 pcs / 27,072 pcs